



FITTING INSTRUCTIONS

Component List

MICO Fitting Instructions
 MICO Maintenance Procedures
 MICO Internal Mechanism Assembly
 MICO Top Shoot Bracket Assembly
 MICO Bottom Shoot Bracket Assembly
 MICO Top Catch Bracket Assembly
 MICO Screw Kit

All models except type -L:

MICO Push Plate Endcaps c/w Screws (Pair)
 MICO Panic Bolt Mechanism Bracket Assembly

All models except types -L and -P:

MICO Hinge Bracket Assembly
 MICO Hinge Bracket Extension Kit
 MICO Standard Lettered Push Plate

Type -L only:

ASSA Lever Handle

Type -P only:

MICO Push Pad Cover Plate


957 RANGE OF EMERGENCY EXIT HARDWARE

No modifications of any kind other than those described in these instructions are permitted.

We advise reading these instructions through to ensure that they are fully understood before attempting to fit the MICO Panic Exit Device.

These units are **HANDED**


Handing must be specified when ordering



DOOR SIZE LIMITATIONS ARE (+/- 2%):

HEIGHT:	2150mm
WIDTH:	1300mm
WEIGHT:	200kg

WIRING DIAGRAM



Designed and manufactured by:

Tindall Engineering Limited, Abryll House,
 Wright Street, OLDHAM OL1 3TF
 Email: sales@mico-tindall.fsnet.co.uk
 Tel: 0161 620 0666 Fax: 0161 620 3966



