



INT PE

The MICO INT Range of Multipoint, surface fitted **Panic & Emergency (PE)** devices offers single handed means of escape should an emergency event arise.

Push pad, full width push plate and heavy duty lever handle options are all available to meet the mandatory BS EN 179 Emergency Escape and BS EN 1125 Panic Escape standards.

OPERATION

Entry Method: (Optional) outside access devices (OAD) option available from key driven to pad-lockable devices.

Exit Method: Single action to escape at all times via push pad, full width push plate or heavy duty lever handle.

FEATURES

- Tested to over 1,000,000 cycles
- Surface fitted
- Automatic bolting
- 2 & 3 point bolting options
- Optional bolt status micro-switch

BENEFITS

- Tested and approved up to SR6 (on selected doorsets)
- Emergency escape versions fully tested and certified to BS EN 179:2008 and CE/UKCA Marked
- Panic escape versions fully tested and certified to BS EN 1125:2008 and CE/UKCA Marked



INT-3 PE1



INT-3 PE2




INT-3 PE3



Product Performance Chart - Indicates product has been certificated or tested & approved as part of a complete doorset assembly																			
LPS 1175								SECURITY								SAFETY			
Issue 7	SR1	SR2	SR3	SR4	SR5	SR6	SR7	SR8	LPS 1673 (AR.)								EN 1125	EN 1522 FB1-7	ISO 16933 EXV 15
Issue 8	A	B	C	D	E	F	G	H	TIME	A	B	C	D	FEBR (min)	EN 1627	STS 202	PAS 24	LPS 2081	
20 Min									300 SEC					60	RC6	BR6		SRB	EN 179
15 Min									240 SEC						RC5	BR5			UL 752 Level 1-10
10 Min	A10	B10	C10	D10					180 SEC					15	RC4	BR4			ASTM F2927 Cat 1
5 Min									120 SEC						RC3	BR3			CERTIFIRE
3 Min									60 SEC					5	RC2	BR2		SRA	BS 476-22
1 Min									30 SEC						RC1	BR1			GR5
																			GR4
																			GR3
																			GR2
																			GR1




TECHNICAL DRAWINGS



CODING SYSTEM

The MICO INT has a simple code that covers the chosen methods of entry and exit, followed by additional options.

Example Order Code – MICO INT-3 PE1



Range	Bolts	Exit	Entry	Additional Options
MICO INT	2	PE1 - Emergency push pad	-	(BSM) Bolt status micro switch
		PE2 - Panic Full width push plate		
	3	PE3 - Emergency Heavy duty lever		

EXAMPLE ENTRY/EXIT DIRECTIONS

